
TA-AX401

SERVICE MANUAL

US Model



SPECIFICATIONS

AUDIO POWER SPECIFICATIONS

POWER OUTPUT AND TOTAL HARMONIC DISTORTION:

With 8 ohm loads both channels driven, from 20 – 20,000 Hz; rated 135 watts per channel minimum RMS power, with no more than 0.9% total harmonic distortion from 250 milliwatts to rated output.

Amplifier section

Power bandwidth (IHF) 30 Hz - 30 kHz (8 ohms, 65 watts)

Dynamic headroom 1.7 dB ('78 IHF)

Harmonic distortion Less than 0.9% at rated output PHONO: RIAA equalization curve

TUNER, CD, VIDEO, TAPE: 30 Hz - 30 kHz ±3 dB

Damping factor 27 (8 ohms, 1 kHz)

Input

Input jack	Jack type	Sensitivity	Impedance	S/N (weighting network, input level)
PHONO MM	Phono	3.0 mV	50 kilohms	71 dB 75 dB* (A, 3.0 mV)
TUNER CD VIDEO TAPE	Phono	250 mV	50 kilohms	92 dB 83 dB * (A, 250 mV)

* '78 IHF

Output

REC OUT	Phono jacks	Voltage 150 mV Impedance 1 kilohm
SPEAKERS		Accepts speakers of 8 - 16 ohms.
HEADPHONES	Stereo phone jack	Accepts low and high impedance headphones.

GRAPHIC EQUALIZER controls

Boost/cut range: ±8 dB (100 Hz, 330 Hz,

1 kHz, 3.3 kHz) : ±6 dB (10 kHz)

General

System Preamplifier: Low-noise, high-gain equalizer

amplifier

Power amplifier: Pure-complementary SEPP

OCL power amplifier with all stages

directly coupled

Power requirements 120 V AC, 60 Hz

Power consumption 235 W

AC outlets 3 switched, total 100 watts max.

Dimensions Approx. 430 × 130 × 355 mm (w/h/d)

(17 × 5¹/₈ × 14 inches)

Weight Approx. 8.5 kg (18 lb 12 oz)

Supplied accessory RM-S104 Remote commander (1)

Design and specifications subject to change without notice.



TABLE OF CONTENS

Section	$n = \frac{Title}{2}$	Page
	ENERAL Location of Controls	
2. DI	ISASSEMBLY	
2-1.	Removal of The Front Panel	. 4
2-2.	Removal of The Q511	4
3. El	LECTRICAL ADJUSTMENTS	į
4. DI	AGRAMS	
4-1.	Block Diagram	6
4-2.	Circuit Boards Location	Ç
4-3.	Printed Wiring Boards	10
4-4.	Schematic Diagram —MAIN Section—	15
4-5.	Schematic Diagram —DISPLAY Section—	19
4-6.	Semiconductor Lead Layouts	22
5. EX	(PLODED VIEWS	
5-1.	Case, Front Panel Section	23
5-2.	Chassis Section	24
6. EL	ECTRICAL PARTS LIST	25

SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety check before releasing the set to the customer:

Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

LEAKAGE TEST


The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microampers). Leakage current can be measured by any one of three methods.

- A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
- 2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.

SAFETY-RELATED COMPONENT WARNING!!


COMPONENTS IDENTIFIED BY MARK A OR DOTTED LINE WITH MARK ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)



SECTION 1 GENERAL


1-1. LOCATION OF CONTROLS



- 1 SYSTEM POWER switch
- 2 5 BAND SPECTRUM ANALYZER display
- 3 5 BAND STEREO GRAPHIC EQUALIZER controls and indicators
- 4 VOLUME control
- 5 SPEAKERS selector

- 6 HEADPHONES jack (stereo phone jack)
- 7 Remote control sensor
- 8 Function selectors
- 9 DBFB (Dynamic Bass Feedback) switch and indicator
- 10 BALANCE control

RM-S104



- [11] CD player operation buttons
 - CD ►: Selects the CD function and starts CD playback.
- 12 Tape deck operation buttons

DECK B operation buttons (also for single tape deck)
DECK B ◀/►: Select tape function (DECK B) and start tape playback.

●: Operates only when it is pressed together with DECK B ◀/►.

DECK A operation buttons


DECK A **◄/►**: Select tape function (DECK A) and start tape playback.

- 13 Function selectors
- 14 POWER button
- 15 DBFB button
- 16 TUNER PRESET buttons
- 17 VOL (volume) control buttons


SECTION 2 DISASSEMBLY

Note: Follow the disassembly procedure in the numerical order given.

2-1. REMOVAL OF THE FRONT PANEL




2-2. REMOVAL OF THE Q511



SECTION 3 ELECTRICAL ADJUSTMENT


Bias Adjustment

Procedure:




- 1. Turn ON the power by connecting a digital voltmeter with test pins TB502 (L-CH) and TB602 (R-CH).
- 2. Adjust to 1.5mV with RV501 (L-CH) and RV601 (R-CH) so that the indicator of digital voltmeter when the power is turned ON.


Adjustment Location: main board



4-1. BLOCK DIAGRAM



4-2. CIRCUIT BOARDS LOCATION



-R-CH IS OMISSION-

TA-AX401 TA-AX401 TA-AX401 TA-AX401

Semiconductor Location

 Ref. No.
 Location
 Ref. No.
 Location

 D300
 B-9
 IC902
 D-3

 D503
 H-16
 IC904
 B-4

 D505
 H-22
 IC905
 B-3

 D506
 H-22
 Q100
 D-23

 D604
 H-22
 Q101
 D-23

 D605
 H-18
 Q301
 C-7

 D606
 H-18
 Q302
 C-6

 D700
 G-17
 Q305
 E-19

 D701
 F-20
 Q401
 C-10

 D800
 G-20
 Q402
 C-9

 D801
 G-20
 Q405
 D-18

 D802
 I-26
 Q505
 I-18

 D803
 I-26
 Q507
 H-22

 D804
 I-26
 Q508
 I-18

 D805
 I-26
 Q509
 I-16

 D806
 G-25
 Q511
 J-19

 D807
 G-31
 Q512
 I-16

 D809
 G-23
 Q605
 J-23
 </tr Ref. No. Location Ref. No. Location IC100 B-25
IC101 E-24
IC102 D-24
IC300 G-7
IC301 E-17
IC400 D-12
IC501 H-17
IC601 H-23
IC700 G-17
IC800 F-23
IC801 H-25
IC900 B-1
IC901 C-20


• o----: parts extracted from the component

-10-

4-3. PRINTED WIRING BOARDS

• Refer to page 22 for Semiconductor Lead Layouts.


1 2 3 4 5 6 7 8	9 10 11 12 13 14 15	16 17 18 19 20 21 22 23 24 25 26	27 28 29 30 31 32
(DISPLAY BOARD)	0500 830 1000 8	SOARD] (CHASSIS) (CH	TM700 SPEAKER IMPEDANCE USE 8-16 Ω A TM700 SPEAKER IMPEDANCE USE 8-16 Ω A B CNB705 CNB70
1C900 D962 3 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	1907 000 1909 000 000 000 000 000 000 000 00	SW Post P	SP OUT BOARD I
10902 9955 10907 109	CAUSE CAUS	1002 10	AC IN AC
CN9902 CN9903 CN9909 CNP909 CN	JOINT (I) BOARD JOINT (I) BOARD COLUMN COLUM	PY700 PY700 PY700 PY354 PY700 PY358 P3358 P358	TO THE TRANSPORMER RY90! RY90! RY90! RY90! RY90!
G. EQ BOARD G. EQ BOARD	MAIN VOL BOARD 1 RV30I-305 RV40I-405 ROARD JOINT (2) BOARD JOINT (2) BOARD OB726 OB72	DB04 DB04 DB05 DB06 DB06 DB06 DB06 DB07 DB07 DB07 DB07 DB08	CNJB00 CNJB00 SYSTEM CONTROL CNJB00 SYSTEM C
SPEAKER 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	To the second se	504 605	3 (9-11) 3 (9-11) 10 10 10 10 10 10 10 10 10 10 10 10 10
TOUTER SW BOARD III SEE TO SEE	RV307 CHARACTER STATE OF THE PROPERTY OF THE P	0512 0505 0508 051 051 051 051 051 051 051 051 051 051	TRANSFORMER TRANSFORMER
POWER SW HEADPHONE III SELECTION OF THE POWER SW SELECTION OF THE POWE	WOTOR + POPO NOTOR + VOL LEI BOARD VOL LEI BOARD		—14—



-17-

—16—

-18-



- All capacitors are in μF unless otherwise noted. pF: $\mu \mu F$ 50WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and $\frac{1}{4}W$ or less unless otherwise specified.
- Voltage and waveforms are dc with respect to ground under no-signal conditions.
- no mark: PHONO
- Voltages are taken with a VOM (Input Impedance 10M Ω). Voltage variations may be noted due to normal production tolerances:

4-6. SEMICONDUCTOR LEAD LAYOUTS

M5F7909 RC7809FA



2SA1215-0Y 2SC2921M-OPY



2SA985A-LK 2SC2275A-P





HZS30-1L HZS30-2L HZS6A1L HZS6C2L HZS7B3L **1SS120**



SEL2210S-C

SEL2810A-C

SEL2510C



HZ5ALL 1S1585

2SD1585-K 2SC2785-HFE



DTC114ES DTC124ES DTC144ES 2SC2603-EF

2SK246BL



10E2 10E2N 11E2

2SB1014 DTA114ES DTA124ES







D300

• IC Block Diagrams


IC102 LC7818



IC300, 400 M5226P



IC901 R50761-439P



SECTION 5 EXPLODED VIEWS

NOTE:

- The mechanical parts with no reference number in the exploded views are not supplied.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- Due to standardization, parts with part number suffix -XX and -X may be different from the parts specified in the components used on the set.
- Color Indication of Appearance Parts Example:


(RED) ... KNOB, BALANCE (WHITE)

†
Cabinet's Color Parts Color

The components identified by mark \(\frac{\hat{\Lambda}}{\text{N}} \) or dotted line with mark \(\frac{\hat{\Lambda}}{\text{N}} \) are critical for safety.


Replace only with part number specified.

5-1. CASE, FRONT PANEL SECTION



Ref.No	Part No.	Description	Remarks	Ref.No	Part No.	Description	Remarks
1	X-4911-214-1	PANEL ASSY, FRONT	1	13	* 4-927 - 892-01	HOLDER (5 GANG), LED	
2	4-908-097-21	KNOB		14	*4-927-893-01	HOLDER, LED	
3	4-925-121-01	KNOB (V2)		901	*1-634-549-11	PC BOARD, VOL LED	
4	*4-931-603-11	- •		902	*A-4334-261-A	MOUNTED PCB, DISPLAY	
5	* 4-921-941-01	CUSHION (FL)		903	*1-634-550-11	PC BOARD, POWER SW	
6		SCREW, +BV (2.6X8) TAPPING		904	*1-634-552-11	PC BOARD, BALANCE VOL	
7		SCREW +BVTT 3X8 (S)		905	*1-634-561-11	PC BOARD, G.EO	
8		HOLDER (FL TUBE)		906	*1-634-551-11	PC BOARD, MAIN VOL	
9	4-930-848-01					PC BOARD, MOTOR	
10	4-924-920-71		l		*1-634-558-11	PC BOARD, JOINT (A)	
11		SCREW (CASE) (M3X8)		RV306		RES, VAR, CARBON 150K/150K (BALA)	NCE)
12	9-911-841-XX			RV307		RES, VAR, CARBON(MOTOR) 100KX2 (

5-2. CHASSIS SECTION



Note: The components identified by mark \bigwedge or dotted line with mark \bigwedge are critical for safety. Replace only with part number specified.

SECTION 6 ELECTRICAL PARTS LIST

NOTE:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- If there are two or more same circuits in a set such as a stereophonic machine, only typical circuit parts may be indicated and capacitors and resistors in other same circuits may be omitted.

CAPACITORS: MF: μ F, PF: $\mu\mu$ F.

RESISTORS

- All resistors are in ohms.
 F: nonflammable

COILS

MMH: mH, UH: μH

SEMICONDUCTORS

In each case, U: μ , for example: UA...: μ A..., UPA...: μ PA..., UPC...: μ PD...

The components identified by mark \(\underbrack \) or dotted line with mark \(\underbrack \) are critical for safety.

Replace only with part number specified.

Ref.No	Part No.	Description				Re	ef.No	Part No.	Description			
901	+1-634-540-11	PC BOARD, VOL LED				l c	356	1-126-301-11	ELECT	1MF	200/	50V
902			N AV								20%	
903		MOUNTED PCB, DISF					357	1-124-045-00		4.7MF	20%	50V
		PC BOARD, POWER S					358	1-124-045-00		4.7MF	20%	50V
904		PC BOARD, BALANCE	VOL				400	1-126-163-11		4.7MF	20%	50V
905	*1-634-561-11	PC BOARD, G.EQ				0	401	1-161-374-11	CERAMIC	0.0015MF	20%	16V
906		PC BOARD, MAIN VO	L				402	1-126-163-11		4.7MF	20%	50V
907		PC BOARD, MOTOR					403	1-161-020-11		0.039MF	10%	16V
908		PC BOARD, JOINT (A)				404	1-124-254-00		0.68MF	20%	50V
909		PC BOARD, SP SW					405	1-162-840-11		0.012MF	10%	16V
910	*1-634-555-11	PC BOARD, HEADPH	ONE			C.	406	1-124-464-11	ELECT	0.22MF	20%	50V
911	*1-634-548-11	PC BOARD, PS				C4	407	1-161-044-00	CERAMIC	0.0039MF	10%	16V
912		PC BOARD, SP OUT				C4	408	1-162-849-11	CERAMIC	0.068MF	10%	16V
913	*A-4334-260-A	MOUNTED PCB, MAII	N			C4	409	1-161-040-00	CERAMIC	0.0012MF		16V
914	*1-634-559-11	PC BOARD, JOINT (B))			C	410	1-161-494-00	CERAMIC	0.022MF		25V
915	*1-634-560-11	PC BOARD, JOINT (C)			C	411	1-162-289-31	CERAMIC	390PF	10%	50V
916	1-533-183-11	HOLDER, FUSE				l c	412	1-161-329-00	CERAMIC	0.0068MF	20%	16V
917	∧ .1-575-105-11	CORD, POWER				l C4	413	1-124-438-00	ELECT	1MF	20%	50V
						l C	414	1-124-254-00		0.68MF	20%	50V
	CA	APACITOR				C	453	1-162-282-31	CERAMIC	100PF	10%	50V
	_					l C	454	1-126-059-11		10MF	20%	50V
C1	<u></u> 1−161−744−00	CERAMIC	0.01MF		400V							
C101	1-162-282-31		100PF	10%	50V	C4	455	1-162-211-31	CERAMIC	33PF	5%	50V
C102	1-126-059-11	ELECT	10MF	20%	50V	C4	457	1-124-045-00	ELECT	4.7MF	20%	50V
C103	1-126-161-11	ELECT	2.2MF	20%	50V	C4	458	1-124-045-00	ELECT	4.7MF	20%	50V
C105	1-130-480-00	MYLAR	0.0056MF	5%	50V	C	500	1-124-045-00	ELECT	4.7MF	20%	50V
						C!	502	1-126-022-11	ELECT	47MF	20%	16V
C106	1-130-473-00		0.0015MF	5%	50V							
C107	1-126-300-11	-	0.47MF	20%	50V		503	1-102-233-00		33PF	10%	500V
C108	1-126-049-11		22MF	20%	25V		504	1-136-163-00		0.068MF	5%	50V
C110	1-162-282-31		100PF	10%	50V		505	1-126-876-11		10MF	20%	63V
C201	1-162-282-31	CERAMIC	100PF	10%	50V		506	1-126-880-11		100MF	20%	63V
0202	11260E0 11	EL EOT	10845	2007	50V	l C	514	1-136-159-00	FILM	0.033MF	5%	50V
C202 C203	1-126-059-11 1-126-161-11		10MF 2.2MF	20% 20%	50V 50V	ے ا	600	1-124-045-00	ELECT	4.7MF	20%	50V
C205	1-130-480-00		0.0056MF	5%	50V		602	1-126-022-11		4.7MF	20%	16V
C205	1-130-473-00		0.0036WF		50V		603	1-102-233-00		33PF	10%	500V
C207	1-126-300-11		0.47MF	5% 20%	50V			1-136-163-00		0.068MF		50V
G207	1-120-300-11	ELECT	U.47 IVIT	20%	30 V		605	1-126-876-11		10MF	5% 20%	63V
C208	1-126-049-11	ELECT	22MF	20%	25V				-		/0	
C210	1-162-282-31	CERAMIC	100PF	10%	50V	C6	606	1-126-880-11	ELECT	100MF	20%	63V
C300	1-126-163-11	ELECT	4.7MF	20%	50V	C6	614	1-136-159-00	FILM	0.033MF	5%	50V
C301	1-161-374-11	CERAMIC	0.0015MF	20%	16V	C7	700	1-126-022-11	ELECT	47MF	20%	10V
C302	1-126-163-11	ELECT	4.7MF	20%	50V	C7	701	1-124-443-00	ELECT	100MF	20%	6.3V
						C7	702	1-126-059-11	ELECT	10MF	20%	50V
C303	1-161-020-11		0.039MF	10%	16V		700	1 105 555 11	5. 507	471.45		400.
C304	1-124-254-00		0.68MF	20%	50V			1-126-022-11		47MF	20%	10V
C305	1-162-840-11		0.012MF	10%	16V			1-161-494-00		0.022MF		25V
C306	1-124-464-11		0.22MF	20%	50V			.1-126-358-11		10000MF	20%	71V
C307	1-161-044-00	CERAMIC	0.0039MF	10%	16V			.1-126-358-11 1-126-027-11		10000MF	20%	71V
C308	1-162-849-11	CERAMIC	0.068MF	10%	16V	"	JJ7	1 120 02/-11	LLLUI	1000MF	20%	25V
C309	1-161-040-00		0.0012MF	/0	16V	C	805	1-126-027-11	ELECT	1000MF	20%	25V
C310	1-161-494-00		0.022MF		25V			1-126-059-11		10MF	20%	50V
C311	1-162-289-31		390PF	10%	50V			1-124-997-11		470MF	20%	10V
C312	1-161-329-00		0.0068MF	20%	16V			1-126-376-11		470MF	20%	25V
								1-124-997-11		470MF	20%	10V
C313	1-124-438-00		1MF	20%	50V		010	1 100 000 11	FLEOT	00145	0004	501/
C314	1-124-254-00		0.68MF	20%	50V			1-126-233-11		22MF	20%	50V
C353	1-162-282-31		100PF	10%	50V			1-124-122-11		100MF	20%	35V
C354	1-126-059-11		10MF	20%	50V			1-126-022-11		47MF	20%	10V
C355	1-162-211-31	GERAMIC	33PF	5%	50V			1-124-122-11		100MF	20%	35V
						1 08	323	1-161-494-00	CERAIVIIC	0.022MF		25V

Ref.No	Part No.	Description				Ref.No	Part No.	Description
C904	1-130-471-00	MYLAR	0.001MF	5%	50V	CNP906	*1-569-602-11	(MAIN)PIN, CONNECTOR 11P
C906	1-161-494-00		0.022MF	3/0	25V			PLUG, CONNECTOR 2P
C907	1-126-049-11		22MF	20%	25V			PIN, CONNECTOR 11P
C908	1-126-301-11		1MF	20%	50V			PIN, CONNECTOR, 3P
C909	1-126-059-11		10MF	20%	50V			,,
						CP901	1-233-081-11	COMPOSITION CIRCUIT BLOCK
C910	1-126-059-11		10 M F	20%	50V	CP902		COMPOSITION CIRCUIT BLOCK
C911	1-161-494-00		0.022MF		25V	CP903	1-233-081-11	COMPOSITION CIRCUIT BLOCK
C912	1-101-361-00		150PF	5%	50V			DIODE 100100
C913	1-101-361-00		150PF	5%	50V	D300	8-719-912-20	
C915	1-126-161-11	ELECI	2.2 M F	20%	50V	D503 D504		DIODE 181585
C916	1-126-049-11	FLECT	22MF	20%	25V	D504		DIODE 1S1585 DIODE HZS30-1L
C917	1-126-161-11		2.2MF	20%	50V	D506		DIODE HZS30-1L
C918	1-161-494-00		0.022MF	_0/0	25V		0 715 504 21	5,052 1,2000 12
C919	1-162-306-11		0.01MF	20%	16V	D603	8-719-815-85	DIODE 1S1585
C920	1-162-306-11	CERAMIC	0.01MF	20%	16V	D604	8-719-815-85	DIODE 1S1585
						D605		DIODE HZS30-1L
C921	1-162-306-11		0.01MF	20%	16V	D606		DIODE HZS30-1L
C925	1-162-286-31		220PF	10%	50V	D700	8-719-200-23	DIODE 11E2
C926	1-161-494-00		0.022MF		25V		0 710 010 00	0,005,100,00
C927 C950	1-161-494-00		0.022MF	2007	25V	D701		DIODE 1SS120
C350	1-123-357-00	ELECT	22 M F	20%	35V		<u>^</u> .8-719-200-80 <u>^</u> .8-719-200-80	
C951	1-123-357-00	FLECT	22MF	20%	35V	D802	8-719-200-00	
C953	1-124-257-00		2.2MF	20%	50V	D803	8-719-200-02	
C955	1-136-158-00		0.027MF	5%	50V	5000	0 713 200 02	DIODE 1022
C956	1-136-158-00		0.027MF	5%	50V	D804	8-719-200-02	DIODE 10E2
C957	1-124-257-00		2.2MF	20%	50V	D805	8-719-200-02	
						D806	8-719-912-20	DIODE 1SS120
C958	1-124-257-00		2.2MF	20%	50V	D807	8-719-200-77	DIODE 10E2N
C960	1-161-329-00		0.0068MF	20%	16V	D808	8-719-933-40	DIODE HZS602L
C961	1-161-329-00		0.0068MF	20%	16V			
C962	1-124-257-00		2.2MF	20%	50V	D809	8-719-912-20	
C964	1-161-327-00	CERAMIC	0.0033MF	20%	16V	D814		DIODE HZS30-2L
C965	1-161-375-00	CERAMIC	0.0022MF	20%	16V	D815 D901	8-719-912-20	DIODE HZS6A1L DIODE 1SS120
C966	1-124-257-00		2.2 M F	20%	50V	D905	8-719-933-48	
C968	1-162-293-31		820PF	10%	50V	5303	0 713 333 40	DIODE 11237532
C969	1-162-293-31		820PF	10%	50V	D906	8-719-301-38	DIODE SEL2210S-C
C970	1-124-257-00		2.2MF	20%	50V	D907		DIODE SEL2210S-C
						D908	8-719-301-38	DIODE SEL2210S-C
C972	1-162-290-31		470PF	10%	50V	D909		DIODE SEL2210S-C
C973	1-162-290-31		470PF	10%	50V	D910	8-719-301-38	DIODE SEL2210S-C
C974	1-124-257-00		2.2MF	20%	50V		0.710.051.11	DIODE HZEALL
C975 C976	1-126-163-11 1-161-494-00		4.7MF	20%	50V	D911		DIODE 155120
03/0	1-101-454-00	CENAMIC	0.022 M F		25V	D913 D918		DIODE 1SS120 DIODE SEL2510C
C977	1-124-443-00	ELECT	100MF	20%	10V	D926		DIODE 1SS120
C980	1-161-374-11		0.0015MF	20%	16V	D927		DIODE SEL2810A-C
C981	1-126-163-11		4.7MF	20%	50V			
						D950	8-719-912-20	DIODE 1SS120
		OUTLET, AC (POLAR				D951	8-719-912-20	DIODE 1SS120
	*1-566-210-11					D952	8-719-912-20	
	1-566-213-11			S 001)	D953	8-719-912-20	
	* 1-565-354-11 * 1-561-650-00					D954	8-719-912-20	DIODE 1SS120
0113702	. 1 201-020-00	JOONET, COMMECTO	IV JI			D955	8-719-912-20	DIODE 1SS120
CN.1903	* 1-561-650-00	SOCKET, CONNECTO	R 5P			D955	8-719-912-20	
	* 1-561-652-00					D957	8-719-912-20	
CNJ905	1-565-296-11					D958	8-719-912-20	
CNJ906	* 1-569-597-11	HOUSING, CONNECT	OR 11P			D959	8-719-912-20	DIODE 1SS120
CNJ907	*1-562-935-11	SOCKET, CONNECTO	R 11P					
04/070	. 1 560 500	DIN 00111150705				D960	8-719-912-20	
	*1-569-598-11					D961	8-719-912-20	
	* 1-569-598-11 * 1-564-321-00					D962 D963	8-719-912-20 8-719-933-33	
	* 1-569-596-11					D903	0-/19-933-33	DIODE HZS6A1L
	*1-569-599-11					F1	1.1-532-748-11	FUSE, GLASS TUBE
		,				1	11	. 100, 00.00 1000
CNP809	*1-569-599-11	PIN, CONNECTOR 3P	1			FL901	1-519-520-11	INDICATOR TUBE, FLUORESCENT
	*1-565-353-11					1		
	1-506-906-11					IC100	8-759-112-93	
	1-506-906-11					IC101	8-759-208-14	
UNP904	* 1-560-443-11	PIN, CONNECTOR 12	٢			IC102	8-759-802-52	
CNP905	* 1-565-295-11	PLUG, CONNECTOR	4P			IC300 IC301	8-759-602-04 8-759-112-93	IC M5226P IC UPC4570HA-1
	*1-566-690-11			OR (2)	5MM) 2P	10301	0 / 03 112-33	IO OF OGSTONAL
		,	,	(.	, - -	•		

Note: The components identified by mark \bigwedge or dotted line with mark \bigwedge are critical for safety. Replace only with part number specified.

Ref.No	Part No.	<u>Description</u>	Ref.No	Part No.	Description			
IC400	8-759-602-04	IC M5226P	R103	1-249-416-11	CARBON	820	5%	1/4W
IC501	8-759-144-04		R104	1-247-897-11		560K	5%	1/4W
IC601	8-759-144-04		R105	1-249-437-11		47K	5%	1/4W
IC700		IC UPC1237HA	R106	1-249-409-11	CARBON	220	5%	1/4W
IC800	8-759-982-10	IC RC7809FA	R107	1-249-441-11	CARBON	100K	5%	1/4W
IC801	8-759-604-49	IC M5F7909	R108	1-249-418-11	CARRON	1.2K	5%	1/4W
IC900			R110	1-249-418-11		1.2K	5%	1/4W
IC901		IC M50761-258P	R111	1-249-433-11		22K	5%	1/4W
IC902	8-759-820-07	IC LC7566	R112	1-249-418-11		1.2K	5%	1/4W
IC903	8-759-112-93	IC UPC4570HA-1	R114	1-249-413-11	CARBON	470	5%	1/4W
IC904	8-759-112-93	IC UPC4570HA-1	R116	1-249-418-11	CARBON	1.2K	5%	1/4W
IC905		IC UPC4570HA-1	R200	1-249-441-11		100K	5%	1/4W
			R201	1-249-411-11		330	5%	1/4W
J100		JACK, PIN 6P (PHONO/CD/VIDEO AUDIO IN)	R202	1-249-441-11		100K	5%	1/4W
J101 J700		JACK, PIN 6P (TUNER/TAPE IN, TAPE REC OUT) JACK, LARGE TYPE (HEADPHONES)	R203	1-249-416-11	CARBON	820	5%	1/4W
3700	1-307-603-31	JACK, LARGE TIPE (HEADPHONES)	R204	1-247-897-11	CARBON	560K	5%	1/4W
L500	*1-420-872-00	COIL, AIR CORE	R205	1-249-437-11		47K	5%	1/4W
L600	*1-420-872-00	COIL, AIR CORE	R206	1-249-409-11		220	5%	1/4W
L901	1-410-521-11	INDUCTOR 100UH	R207	1-249-441-11		100K	5%	1/4W
0100	0 700 000 63	TRANSISTOR REALISTS	R208	1-249-418-11	CARBON	1.2K	5%	1/4W
Q100 Q101		TRANSISTOR DTA124ES TRANSISTOR DTC144ES	R210	1-249-418-11	CARRON	1.2K	5%	1/4W
Q301		TRANSISTOR 2SK246-BL	R212	1-249-418-11		1.2K	5%	1/4W
Q302		TRANSISTOR 2SC2603-EF	R214	1-249-413-11		470	5%	1/4W
Q305		TRANSISTOR 2SC3622A-LK	R216	1-249-418-11		1.2K	5%	1/4W
			R300	1-249-436-11	CARBON	39K	5%	1/4W
Q401		TRANSISTOR 2SK246-BL	D 201	1 047 001 00	CADDON	1001/	E0/	1 / 414/
Q402 Q405		TRANSISTOR 2SC2603-EF TRANSISTOR 2SC3622A-LK	R301 R302	1-247-881-00 1-249-425-11		120K 4.7K	5% 5%	1/4W 1/4W
Q505		TRANSISTOR 25C3022A-ER TRANSISTOR 2SD1585-K	R303	1-249-425-11		1.5K	5%	1/4W 1/4W
Q507		TRANSISTOR 2SA985A-QP	R304	1-247-903-00		1M	5%	1/4W
-		•	R305	1-249-409-11		220	5%	1/4W
Q508		TRANSISTOR 2SC2785-HFE						
Q509		TRANSISTOR 2SA1115-HFE	R306	1-249-438-11		56K	5%	1/4W
Q511 Q512		TRANSISTOR 2SC2921M-OPY TRANSISTOR 2SA1215-OY	R307 R308	1-249-426-11 1-249-412-11		5.6K 390	5% 5%	1/4W 1/4W
Q512 Q514		TRANSISTOR 2SA1215-01 TRANSISTOR 2SC1841-PAFAEA	R309	1-249-412-11		100K	5%	1/4W
Q 01.	0 /25 210 01	THE TOTAL PROPERTY OF THE PARTY	R310	1-249-441-11		100K	5%	1/4W
Q605		TRANSISTOR 2SD1585-K						
Q607		TRANSISTOR 2SC2275A-P	R311	1-249-421-11		2.2K	5%	1/4W
Q608 Q609		TRANSISTOR 2SC2785-HFE	R327 R330	1-249-417-11		1K	5%	1/4W 1/4W
Q609 Q611	8-729-320-97	TRANSISTOR 2SA1115-HFE TRANSISTOR 2SC2921M-OPY	R352	1-249-417-11 1-249-438-11		1K 56K	5% 5%	1/4W 1/4W
QUII	0 723 020 37	11/11/01010101 2002321W 01 1	R353	1-249-426-11		5.6K	5%	1/4W
Q612		TRANSISTOR 2SA1215-OY						
Q614		TRANSISTOR 2SA1841-PAFAEA	R354	1-249-435-11		33K	5%	1/4W
Q700		TRANSISTOR DTA124ES	R356	1-249-425-11		4.7K	5%	1/4W
Q804 Q872		TRANSISTOR 2SD1387 TRANSISTOR 2SB1116	R358 R359	1-249-429-11 1-249-441-11		10K 100K	5% 5%	1/4W 1/4W
QUIZ	6 725 110 01	TRANSISTOR ZODITIO	R400	1-249-436-11		39K		1/4W
Q900	8-729-620-05	TRANSISTOR 2SC2603-EF					,,,	
Q901	8-729-620-05	TRANSISTOR 2SC2603-EF	R401	1-247-881-00		120K	5%	1/4W
Q902 Q903	8-729-900-80	TRANSISTOR DTC114ES TRANSISTOR 2SC2603-EF	R402 R403	1-249-425-11 1-249-419-11		4.7K 1.5K	5%	1/4W 1/4W
Q903 Q904	8-729-620-05 8-729-119-76	TRANSISTOR 2SC2003-EF TRANSISTOR 2SA1115-HFE	R403	1-249-419-11		1.5K 1M	5% 5%	1/4W 1/4W
₹20 4	5 723 113 70	THE TOTAL PORTION AND ADDRESS OF THE PARTY O	R405	1-249-409-11		220	5%	1/4W
Q905	8-729-900-61	TRANSISTOR DTA114ES						
Q908	8-729-111-29	TRANSISTOR 2SD1616A-K	R406	1-249-438-11		56K	5%	1/4W
Q909	8-729-118-01	TRANSISTOR 2SB1116	R407	1-249-426-11		5.6K	5%	1/4W
Q913 Q914	8-729-620-05 8-729-620-05	TRANSISTOR 2SC2603-EF TRANSISTOR 2SC2603-EF	R408 R411	1-249-412-11 1-249-421-11		390 2.2K	5% 5%	1/4W 1/4W
QJI4	0 729 020 03	TRANSISTOR 2302003 EI	R427	1-249-417-11		1K	5%	1/4W
Q915	8-729-620-05							
Q916		TRANSISTOR DTA124ES	R430	1-249-417-11		1K	5%	1/4W
Q917	8-729-900-63		R431	1-247-901-11		820K	5%	1/4W
Q918 Q919	8-729-900-63 8-729-900-36	TRANSISTOR DTA124ES TRANSISTOR DTC124ES	R452 R453	1-249-438-11 1-249-426-11		56K 5.6K	5% 5%	1/4W 1/4W
G212	0-723-300-30	TRANSISTOR DIVIZACO	R454	1-249-426-11		33K	5% 5%	1/4W 1/4W
Q922	8-729-900-63	TRANSISTOR DTA124ES						-•
		COLOTOR	R456	1-249-425-11		4.7K	5%	1/4W
	RE	SISTOR	R459 R500	1-249-441-11 1-249-441-11		100K 100K	5%	1/4W
R100	1-249-441-11	CARBON 100K 5% 1/4W	R502	1-249-441-11		100K	5% 5%	1/4W 1/4W
R101	1-249-411-11		R503	1-249-438-11		56K	5%	1/4W
R102	1-249-441-11		-	· -	-		, •	

Ref.No	Part No.	Description					Ref.No	Part No.	Description			
R504	1-249-417-11		1K	5%	1/4W	1	R914	1-249-433-11		22K	5%	1/4W
R505 R507	1-249-438-11 1-249-431-11		56K 15K	5% 5%	1/4W 1/4W		R915 R916	1-249-429-11 1-249-429-11		10K 10K	5% 5%	1/4W 1/4W
R508	1-249-419-11		1.5K	5%	1/4W	ŀ	R917	1-249-433-11		22K	5%	1/4W
R509	1-249-423-11	CARBON	3.3K	5%	1/4W		R918	1-249-441-11	CARBON	100K	5%	1/4W
	<u>^</u> .1-247-688-11		10	5%		F	R919	1-249-433-11		22K 1K	5% 5%	1/4W 1/4W
R511	1-247-688-11 1-214-789-00	METAL PLATE	10 0.1	5%	1/4W	F	R920 R921	1-249-417-11 1-249-433-11		22K	5%	1/4W
R513	1-214-789-00	METAL PLATE	0.1			l	R922	1-249-441-11		100K	5%	1/4W
R514	1-249-417-11	CARBON	1K	5%	1/4W		R923	1-249-441-11	CARBON	100K	5%	1/4W
	<u>^</u> .1-247-713-11 <u>^</u> .1-247-713-11		1K 1K	5% 5%	1/4W 1/4W	F	R924 R925	1-249-429-11 1-249-413-11		10K 470	5% 5%	1/4W 1/4W
	⚠.1-247-700-11	CARBON	100	5%	1/4W	F	R926	1-249-413-11		470	5%	1/4W
R531	1-249-430-11	CARBON	12K	5%	1/4W		R927	1-249-413-11		470	5%	1/4W
R532	1-247-727-11		10	5%	1/2W		R928	1-249-413-11		470	5%	1/4W
R533 R534	1-249-437-11 1-247-727-11		47K 10	5% 5%	1/4W 1/2W		R929 R930	1-249-413-11 1-249-417-11		470 1K	5% 5%	1/4W 1/4W
	<u>↑</u> .1-212-942-00		2.2	5%	1/2W	F	R931	1-249-419-11		1.5K	5%	1/4W
R597	1-215-869-11	METAL OXIDE	1K	5%	1W	F	R932	1-249-394-11		12	5%	1/4W
R600	1-249-441-11	CARBON	100K	5%	1/4W		R933	1-249-394-11	CARBON	12	5%	1/4W
R602	1-249-417-11		1K	5%	1/4W		R934	1-249-441-11		100K	5%	1/4W
R603 R604	1-249-438-11 1-249-417-11		56K 1K	5% 5%	1/4W 1/4W		R937 R938	1-249-441-11 1-249-433-11		100K 22K	5% 5%	1/4W 1/4W
R605	1-249-438-11		56K	5%	1/4W		R939	1-249-433-11		22K	5%	1/4W
R607	1-249-431-11	CARBON	15K	5%	1/4W		R940	1-247-903-00	CARBON	1 M	5%	1/4W
R608	1-249-419-11		1.5K	5%	1/4W		R941	1-249-423-11		3.3K	5%	1/4W
R609	1-249-423-11		3.3K	5%	1/4W	F	R942	1-249-433-11 1-249-423-11		22K 3.3K	5% 5%	1/4W 1/4W
	<u></u> 1-247-688-11 1.1-247-688-11 1.1-247-688-11		10 10	5% 5%	1/4W 1/4W	F	R946 R948	1-249-413-11		470	5%	1/4W
R612		METAL PLATE	0.1	470	-,	·	R949	1-249-417-11		1K	5%	1/4W
R613		METAL PLATE	0.1				R950	1-249-441-11		100K	5%	1/4W
R614	1-249-417-11		1K	5%	1/4W		R951	1-249-441-11		100K	5%	1/4W
	1. 1. 1. 1. 1. 1. 1. 1.		1K 1K	5% 5%	1/4W 1/4W	F F	R952 R953	1-249-417-11 1-247-885-00		1K 180K	5% 5%	1/4W 1/4W
	A.1-247-700-11		100	5%	1/4W	F	R954	1-249-429-11		10K	5%	1/4W
R631	1-249-430-11	CARBON	12K	5%	1/4W		R955	1-249-405-11	CARBON	100	5%	1/4W
R632	1-247-727-11		10	5%	1/2W		R956	1-249-441-11		100K	5%	1/4W
R633 R634	1-249-438-11 1-247-727-11		56K 10	5% 5%	1/4W 1/2W		R957 R958	1-249-439-11 1-249-424-11		68K 3.9K	5% 5%	1/4W 1/4W
	A .1-212-942-00		2.2	5%	1/2W	F	R959	1-247-901-11		820K	5%	1/4W
R697	1-215-869-11	METAL OXIDE	1K	5%	1W	F	R960	1-249-441-11	CARBON	100K	5%	1/4W
R701	1-249-427-11		6.8K	5%	1/4W		R961	1-249-441-11		100K	5%	1/4W
R702 R703	1-249-441-11 1-249-441-11	-	100K 100K	5% 5%	1/4W 1/4W		R962 R963	1-249-440-11 1-249-424-11		82K 3.9K	5% 5%	1/4W 1/4W
R704	1-249-433-11		22K	5%	1/4W		R964	1-247-903-00		1M	5%	1/4W
R705	1-249-436-11	CARBON	39K	5%	1/4W		R965	1-249-441-11		100K	5%	1/4W
	A.1-206-726-00		1.1K	5%	3W	F	R966	1-249-438-11		56K	5%	1/4W
	<u>A</u> .1-249-455-11 <u>A</u> .1-249-455-11		4.7 4.7	5% 5%	1/4W 1/4W	F F	R967 R968	1-249-423-11 1-247-903-00		3.3K 1M	5% 5%	1/4W 1/4W
R805	1-249-425-11		4.7K	5%	1/4W	•	R969	1-249-441-11		100K	5%	1/4W
R806	1-249-397-11		22	5%	1/4W		R970	1-249-438-11		56K	5%	1/4W
R808	1-249-399-11		33	5%	1/4W 1W	F	R971 R972	1-249-423-11 1-247-901-11		3.3K 820K	5% 5%	1/4W 1/4W
R812	1-249-405-11 1-249-405-11		2.2K 100	5% 5%	1/4W	r	R973	1-249-441-11		100K	5%	1/4W
R813	1-249-405-11		100	5%	1/4W		R974	1-249-435-11		33K	5%	1/4W
R814	1-249-415-11		680	5%	1/4W		R975	1-249-423-11		3.3K	5%	1/4W
R815 R903	1-249-426-11 1-249-429-11		5.6K 10K	5% 5%	1/4W 1/4W		R976 R977	1-247-895-00 1-249-441-11		470K 100K	5% 5%	1/4W 1/4W
R903	1-249-429-11		10K	5% 5%	1/4W		R978	1-249-441-11		100	5%	1/4W
R907	1-249-417-11		1K	5%	1/4W		R979	1-249-403-11		68	5%	1/4W
R908	1-249-429-11		10K	5%	1/4W		R980	1-247-903-00		1M	5%	1/4W
R909	1-249-417-11		1K	5%	1/4W		R981 R982A	1-249-441-11 1-249-430-11		100K 12K	5% 5%	1/4W 1/4W
R910 R911	1-249-393-11 1-247-901-11		10 820K	5% 5%	1/4W 1/4W		R982B			100K	5%	1/4W
R913	1-249-433-11		22K	5%	1/4W		R983A			10	5%	1/4W

Note: The components identified by mark \bigwedge or dotted line with mark \bigwedge are critical for safety. Replace only with part number specified.

R983B 1-249-432-11 CARBON 18K 5% 1/4W R985 1-247-751-11 CARBON 20 5% 1/2W R987 1-249-433-11 CARBON 22K 5% 1/4W R989 1-249-433-11 CARBON 22K 5% 1/4W R990 1-249-433-11 CARBON 22K 5% 1/4W R990 1-249-433-11 CARBON 22K 5% 1/4W R991 1-249-433-11 CARBON 22K 5% 1/4W R992 1-249-433-11 CARBON 22K 5% 1/4W R993 1-249-433-11 CARBON 22K 5% 1/4W R993 1-249-433-11 CARBON 22K 5% 1/4W R995 1-249-417-11 CARBON 22K 5% 1/4W R996 1-247-727-11 CARBON 1K 5% 1/4W R996 1-247-727-11 CARBON 1D 5% 1/2W RV301 1-241-021-11 RES, VAR, SLIDE 250K (100Hz) RV302 1-241-021-11 RES, VAR, SLIDE 250K (330Hz) RV303 1-241-021-11 RES, VAR, SLIDE 250K (330Hz) RV304 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV305 1-241-021-11 RES, VAR, SLIDE 250K (10Hz) RV306 1-241-021-11 RES, VAR, SLIDE 250K (10Hz) RV401 1-241-021-11 RES, VAR, SLIDE 250K (10Hz) RV402 1-241-021-11 RES, VAR, SLIDE 250K (10Hz) RV403 1-241-021-11 RES, VAR, SLIDE 250K (10Hz) RV404 1-241-021-11 RES, VAR, SLIDE 250K (10Hz) RV405 1-241-021-11 RES, VAR, SLIDE 250K (10Hz) RV404 1-241-021-11 RES, VAR, SLIDE 250K (10Hz) RV405 1-228-990-00 RES, VAR, SLIDE 250K (10KHz) RV406 1-228-990-00 RES, VAR, SLIDE 250K (10KHz) RV501 1-228-990-00 RES, VAR, SLIDE 250K (10KHz) RV501 1-228-990-00 RES, ADJ, CARBON 1K RV601 1-256-303-21 SWITCH, KEY BOARD (PHONO) SUTCH, KEY BOARD (TUNER) SS 1-554-303-21 SWITCH, KEY BOARD (TUNER) SS 1-554-303-21 SWITCH, KEY BOARD (DBFB) ST 1-554-303-21 SWITCH, KEY BOARD (DBFB) ST 1-554-303-21 SWITCH, KEY BOARD (DBFB) SWITCH, KEY BOARD (SYSTEM POWER) SS 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) SS 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) SS 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) SWITCH, REY BOARD (SYSTEM POWER) TB502 *1-535-115-00 TERMINAL	Ref.No	Part No.	Description
R989 1-249-433-11 CARBON 22K 5% 1/4W R990 1-249-433-11 CARBON 22K 5% 1/4W R991 1-249-433-11 CARBON 22K 5% 1/4W R992 1-249-433-11 CARBON 22K 5% 1/4W R993 1-249-433-11 CARBON 22K 5% 1/4W R995 1-249-417-11 CARBON 22K 5% 1/4W R996 1-247-727-11 CARBON 1K 5% 1/4W R996 1-247-727-11 CARBON 10 5% 1/2W RV301 1-241-021-11 RES, VAR, SLIDE 250K (100Hz) RV302 1-241-021-11 RES, VAR, SLIDE 250K (330Hz) RV303 1-241-021-11 RES, VAR, SLIDE 250K (33Hz) RV304 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV305 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV401 1-241-021-11 RES, VAR, SLIDE 250K (10Hz) RV402 1-241-021-11 RES, VAR, SLIDE 250K (10Hz) RV402 1-241-021-11 RES, VAR, SLIDE 250K (330Hz) RV403 1-241-021-11 RES, VAR, SLIDE 250K (10Hz) RV404 1-241-021-11 RES, VAR, SLIDE 250K (10Hz) RV404 1-241-021-11 RES, VAR, SLIDE 250K (10Hz) RV404 1-241-021-11 RES, VAR, SLIDE 250K (10Hz) RV501 1-228-990-00 RES, VAR, SLIDE 250K (10Hz) RV501 1-228-990-00 RES, ADJ, CARBON 1K RV901 1-515-701-11 RELAY S1 1-554-303-21 SWITCH, KEY BOARD (PHONO) S2 1-554-303-21 SWITCH, KEY BOARD (CD) S4 1-554-303-21 SWITCH, KEY BOARD (CD) S5 1-554-303-21 SWITCH, KEY BOARD (DBFB) S7 1-554-303-21 SWITCH, KEY BOARD (DBFB) S7 1-554-303-21 SWITCH, KEY BOARD (SP) S500 1-571-861-11 TRANSFORMER, POWER TB502 *1-535-115-00 TERMINAL TB703 *1-508-831-12 H TYPE BASE POST TM700 1-536-706-00 TERMINAL TB703 *1-508-831-12 H TYPE BASE POST	R985	1-247-751-11	CARBON 820 5% 1/2W
R990 1-249-433-11 CARBON 22K 596 1/4W R991 1-249-433-11 CARBON 22K 59 1/4W R992 1-249-433-11 CARBON 22K 59 1/4W R993 1-249-433-11 CARBON 22K 59 1/4W R995 1-249-433-11 CARBON 22K 59 1/4W R996 1-247-727-11 CARBON 1K 596 1/2W RV301 1-241-021-11 RES, VAR, SLIDE 250K (10Hz) RV302 1-241-021-11 RES, VAR, SLIDE 250K (10Hz) RV303 1-241-021-11 RES, VAR, SLIDE 250K (33Hz) RV304 1-241-021-11 RES, VAR, SLIDE 250K (1KHz) RV305 1-241-021-11 RES, VAR, SLIDE 250K (1KHz) RV306 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV307 1-238-079-11 RES, VAR, CARBON 150K/150K (BALANCE) RV401 1-241-021-11 RES, VAR, SLIDE 250K (10Hz) RV402 1-241-021-11 RES, VAR, SLIDE 250K (10Hz) RV403 1-241-021-11 RES, VAR, SLIDE 250K (10Hz) RV404 1-241-021-11 RES, VAR, SLIDE 250K (10Hz) RV405 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV406 1-228-990-00 RES, VAR, SLIDE 250K (10KHz) RV401 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV401 1-254-031-11 RES, VAR, SLIDE 250K (10KHz) RV401 1-254-031-11 RES, VAR, SLIDE 250K (10KHz) RV401 1-554-303-21 SWITCH, KEY BOARD (PHONO) S2 1-554-303-21 SWITCH, KEY BOARD (TUNER) S3 1-554-303-21 SWITCH, KEY BOARD (CD) S4 1-554-303-21 SWITCH, KEY BOARD (CD) S5 1-554-303-21 SWITCH, KEY BOARD (CD) S6 1-554-303-21 SWITCH, KEY BOARD (CD) S6 1-554-303-21 SWITCH, KEY BOARD (DBFB) S7 1-554-303-21 SWITCH, KEY BOARD (DBFB) S7 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) S500 1-571-861-11 TRANSFORMER, POWER TB502 *1-535-115-00 TERMINAL TB502 *1-535-115-00 TERMINAL TB703 *1-508-831-12 H TYPE BASE POST TM700 1-536-706-00 TERMINAL BOARD (SP) (SPEAKER)			
R992 1-249-433-11 CARBON 22K 5% 1/4W R993 1-249-433-11 CARBON 22K 5% 1/4W R995 1-249-417-11 CARBON 1K 5% 1/4W R996 1-247-727-11 CARBON 1			
R992 1-249-433-11 CARBON 22K 5% 1/4W R993 1-249-433-11 CARBON 22K 5% 1/4W R995 1-249-417-11 CARBON 1K 5% 1/4W R996 1-247-727-11 CARBON 1	R991	1-249-433-11	CARBON 22K 5% 1/4W
R995 1-249-417-11 CARBON 1K 5% 1/4W R996 1-247-727-11 CARBON 10 5% 1/2W RV301 1-241-021-11 RES, VAR, SLIDE 250K (100Hz) RV302 1-241-021-11 RES, VAR, SLIDE 250K (330Hz) RV303 1-241-021-11 RES, VAR, SLIDE 250K (330Hz) RV304 1-241-021-11 RES, VAR, SLIDE 250K (1KHz) RV305 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV306 1-241-022-11 RES, VAR, SLIDE 250K (10KHz) RV307 1-238-079-11 RES, VAR, CARBON 150K/150K (BALANCE) RV307 1-241-021-11 RES, VAR, SLIDE 250K (100Hz) RV401 1-241-021-11 RES, VAR, SLIDE 250K (100Hz) RV402 1-241-021-11 RES, VAR, SLIDE 250K (100Hz) RV403 1-241-021-11 RES, VAR, SLIDE 250K (100Hz) RV405 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV404 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV501 1-228-990-00 RES, ADJ, CARBON 1K RV501 1-228-990-00 RES, ADJ, CARBON 1K RY901 1-515-701-11 RELAY S1 1-554-303-21 SWITCH, KEY BOARD (PHONO) SWITCH, KEY BOARD (CD) SWITCH, KEY BOARD (VIDEO) S4 1-554-303-21 SWITCH, KEY BOARD (TAPE) SWITCH, KEY BOARD (VIDEO) S6 1-554-303-21 SWITCH, KEY BOARD (DBFB) SWITCH, KEY BOARD (SYSTEM POWER) S7 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) S500 1-571-861-11 TRANSFORMER, POWER TB502 *1-535-115-00 TERMINAL		1-249-433-11	CARBON 22K 5% 1/4W
RV301 1-241-021-11 RES, VAR, SLIDE 250K (100Hz) RV302 1-241-021-11 RES, VAR, SLIDE 250K (330Hz) RV303 1-241-021-11 RES, VAR, SLIDE 250K (1KHz) RV304 1-241-021-11 RES, VAR, SLIDE 250K (1KHz) RV305 1-241-021-11 RES, VAR, SLIDE 250K (1KHz) RV306 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV307 1-238-079-11 RES, VAR, CARBON 150K/150K (BALANCE) RV307 1-238-079-11 RES, VAR, CARBON 150K/150K (BALANCE) RV401 1-241-021-11 RES, VAR, SLIDE 250K (100Hz) RV402 1-241-021-11 RES, VAR, SLIDE 250K (100Hz) RV403 1-241-021-11 RES, VAR, SLIDE 250K (330Hz) RV404 1-241-021-11 RES, VAR, SLIDE 250K (1KHz) RV405 1-228-990-00 RES, VAR, SLIDE 250K (10KHz) RV501 1-228-990-00 RES, ADJ, CARBON 1K RV901 1-515-701-11 RELAY S1 1-554-303-21 SWITCH, KEY BOARD (PHONO) S2 1-554-303-21 SWITCH, KEY BOARD (TUNER) S3 1-554-303-21 SWITCH, KEY BOARD (DBFB) S5 1-554-303-21 SWITCH, KEY BOARD (DBFB) S7 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) S5 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) S500 1-571-861-11 TRANSFORMER, POWER T1			
RV301 1-241-021-11 RES, VAR, SLIDE 250K (100Hz) RV302 1-241-021-11 RES, VAR, SLIDE 250K (330Hz) RV303 1-241-021-11 RES, VAR, SLIDE 250K (330Hz) RV304 1-241-021-11 RES, VAR, SLIDE 250K (3.3KHz) RV305 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV306 1-241-022-11 RES, VAR, CARBON 150K/150K (BALANCE) RV307 1-238-079-11 RES, VAR, CARBON(MOTOR) 100KX2 (VOLUME) RV401 1-241-021-11 RES, VAR, SLIDE 250K (100Hz) RV402 1-241-021-11 RES, VAR, SLIDE 250K (330Hz) RV403 1-241-021-11 RES, VAR, SLIDE 250K (330Hz) RV404 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV405 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV501 1-228-990-00 RES, ADJ, CARBON 1K RV601 1-228-990-00 RES, ADJ, CARBON 1K RY901 1-515-701-11 RELAY S1 1-554-303-21 SWITCH, KEY BOARD (PHONO) S2 1-554-303-21 SWITCH, KEY BOARD (TUNER) S3 1-554-303-21 SWITCH, KEY BOARD (TAPE) S5 1-554-303-21 SWITCH, KEY BOARD (VIDEO) S6 1-554-303-21 SWITCH, KEY BOARD (DBFB) S7 1-554-303-21 SWITCH, KEY BOARD (DBFB) S7 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) S500 1-571-861-11 TRANSFORMER, POWER T1			
RV302 1-241-021-11 RES, VAR, SLIDE 250K (330Hz) RV303 1-241-021-11 RES, VAR, SLIDE 250K (1KHz) RV304 1-241-021-11 RES, VAR, SLIDE 250K (1KHz) RV305 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV306 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV307 1-238-079-11 RES, VAR, CARBON 150K/150K (BALANCE) RV4001 1-241-021-11 RES, VAR, SLIDE 250K (100Hz) RV401 1-241-021-11 RES, VAR, SLIDE 250K (330Hz) RV403 1-241-021-11 RES, VAR, SLIDE 250K (330Hz) RV404 1-241-021-11 RES, VAR, SLIDE 250K (33KHz) RV405 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV501 1-228-990-00 RES, ADJ, CARBON 1K RV601 1-228-990-00 RES, ADJ, CARBON 1K RY901 1-515-701-11 RELAY S1 1-554-303-21 SWITCH, KEY BOARD (PHONO) S2 1-554-303-21 SWITCH, KEY BOARD (TUNER) S3 1-554-303-21 SWITCH, KEY BOARD (TUNER) S4 1-554-303-21 SWITCH, KEY BOARD (TAPE) S5 1-554-303-21 SWITCH, KEY BOARD (VIDEO) S6 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) S500 1-571-861-11 SWITCH, REY BOARD (SYSTEM POWER) S500 1-571-861-11 TRANSFORMER, POWER			
RY303 1-241-021-11 RES, VAR, SLIDE 250K (1KHz) RY304 1-241-021-11 RES, VAR, SLIDE 250K (3.3KHz) RY305 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RY306 1-241-022-11 RES, VAR, CARBON 150K/150K (BALANCE) RY307 1-238-079-11 RES, VAR, CARBON(MOTOR) 100KX2 (VOLUME) RY401 1-241-021-11 RES, VAR, SLIDE 250K (100Hz) RY402 1-241-021-11 RES, VAR, SLIDE 250K (330Hz) RY403 1-241-021-11 RES, VAR, SLIDE 250K (1KHz) RV404 1-241-021-11 RES, VAR, SLIDE 250K (1KHz) RV405 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RY501 1-228-990-00 RES, ADJ, CARBON 1K RY601 1-228-990-00 RES, ADJ, CARBON 1K RY901 1-515-701-11 RELAY S1 1-554-303-21 SWITCH, KEY BOARD (PHONO) S2 1-554-303-21 SWITCH, KEY BOARD (TUNER) S3 1-554-303-21 SWITCH, KEY BOARD (TUNER) S3 1-554-303-21 SWITCH, KEY BOARD (TAPE) S5 1-554-303-21 SWITCH, KEY BOARD (VIDEO) S6 1-554-303-21 SWITCH, KEY BOARD (DBFB) S7 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) S7 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) S7 1-554-303-21 TRANSFORMER, POWER T1 ★1-450-068-11 TRANSFORMER, POWER T2 ★1-449-993-21 TRANSFORMER, POWER TRANSFORMER, POWER TB502 *1-535-115-00 TERMINAL			
RV304 1-241-021-11 RES, VAR, SLIDE 250K (3.3KHz) RV305 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV306 1-241-022-11 RES, VAR, CARBON 150K/150K (BALANCE) RV307 1-238-079-11 RES, VAR, CARBON(MOTOR) 100KX2 (VOLUME) RV401 1-241-021-11 RES, VAR, SLIDE 250K (100Hz) RV402 1-241-021-11 RES, VAR, SLIDE 250K (330Hz) RV403 1-241-021-11 RES, VAR, SLIDE 250K (3.3KHz) RV404 1-241-021-11 RES, VAR, SLIDE 250K (1KHz) RV405 1-241-021-11 RES, VAR, SLIDE 250K (1KHz) RV501 1-228-990-00 RES, ADJ, CARBON 1K RV601 1-228-990-00 RES, ADJ, CARBON 1K RY901 1-515-701-11 RELAY S1 1-554-303-21 SWITCH, KEY BOARD (PHONO) S2 1-554-303-21 SWITCH, KEY BOARD (TUNER) S3 1-554-303-21 SWITCH, KEY BOARD (TUNER) S3 1-554-303-21 SWITCH, KEY BOARD (TUNER) S5 1-554-303-21 SWITCH, KEY BOARD (VIDEO) S6 1-554-303-21 SWITCH, KEY BOARD (DBFB) S7 1-554-303-21 SWITCH, KEY BOARD (DBFB) S7 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) S500 1-571-861-11 TRANSFORMER, POWER T1 ★1-450-068-11 TRANSFORMER, POWER TRANSFORMER, POWER TB502 *1-535-115-00 TERMINAL			
RV306 1-241-022-11 RES, VAR, CARBON 150K/150K (BALANCE) RV307 1-238-079-11 RES, VAR, CARBON(MOTOR) 100KX2 (VOLUME) RV401 1-241-021-11 RES, VAR, SLIDE 250K (100Hz) RV402 1-241-021-11 RES, VAR, SLIDE 250K (330Hz) RV403 1-241-021-11 RES, VAR, SLIDE 250K (1KHz) RV404 1-241-021-11 RES, VAR, SLIDE 250K (1KHz) RV405 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV501 1-228-990-00 RES, ADJ, CARBON 1K RV601 1-228-990-00 RES, ADJ, CARBON 1K RY901 1-515-701-11 RELAY S1 1-554-303-21 SWITCH, KEY BOARD (PHONO) S2 1-554-303-21 SWITCH, KEY BOARD (TUNER) S3 1-554-303-21 SWITCH, KEY BOARD (TUNER) S4 1-554-303-21 SWITCH, KEY BOARD (TAPE) S5 1-554-303-21 SWITCH, KEY BOARD (VIDEO) S6 1-554-303-21 SWITCH, KEY BOARD (DBFB) S7 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) S500 1-571-861-11 SWITCH, ROTARY SLIDE T1			
RV307 1-238-079-11 RES, VAR, CARBON(MOTOR) 100KX2 (VOLUME) RV401 1-241-021-11 RES, VAR, SLIDE 250K (100Hz) RV402 1-241-021-11 RES, VAR, SLIDE 250K (330Hz) RV403 1-241-021-11 RES, VAR, SLIDE 250K (1KHz) RV404 1-241-021-11 RES, VAR, SLIDE 250K (1KHz) RV405 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV501 1-228-990-00 RES, ADJ, CARBON 1K RV601 1-228-990-00 RES, ADJ, CARBON 1K RY901 1-515-701-11 RELAY S1 1-554-303-21 SWITCH, KEY BOARD (PHONO) S2 1-554-303-21 SWITCH, KEY BOARD (TUNER) S3 1-554-303-21 SWITCH, KEY BOARD (TUNER) S3 1-554-303-21 SWITCH, KEY BOARD (TAPE) S5 1-554-303-21 SWITCH, KEY BOARD (VIDEO) S6 1-554-303-21 SWITCH, KEY BOARD (VIDEO) S6 1-554-303-21 SWITCH, KEY BOARD (DBFB) S7 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) S7 1-554-303-21 SWITCH, ROTARY SLIDE T1 ★1-450-068-11 TRANSFORMER, POWER TRANSFORMER, POWER TB502 *1-535-115-00 TERMINAL BOARD (SP) (SPEAKER)	RV305	1-241-021-11	RES, VAR, SLIDE 250K (10KHz)
RV401 1-241-021-11 RES, VAR, SLIDE 250K (100Hz) RV402 1-241-021-11 RES, VAR, SLIDE 250K (330Hz) RV403 1-241-021-11 RES, VAR, SLIDE 250K (1KHz) RV404 1-241-021-11 RES, VAR, SLIDE 250K (1KHz) RV405 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV501 1-228-990-00 RES, ADJ, CARBON 1K RV601 1-228-990-00 RES, ADJ, CARBON 1K RY901 1-515-701-11 RELAY S1 1-554-303-21 SWITCH, KEY BOARD (PHONO) S2 1-554-303-21 SWITCH, KEY BOARD (TUNER) S3 1-554-303-21 SWITCH, KEY BOARD (TUNER) S3 1-554-303-21 SWITCH, KEY BOARD (TUNER) S5 1-554-303-21 SWITCH, KEY BOARD (VIDEO) S6 1-554-303-21 SWITCH, KEY BOARD (VIDEO) S6 1-554-303-21 SWITCH, KEY BOARD (DBFB) S7 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) S500 1-571-861-11 TRANSFORMER, POWER T1 ★1-450-068-11 TRANSFORMER, POWER T2 ★1-449-993-21 TRANSFORMER, POWER TB502 *1-535-115-00 TERMINAL TB602 *1-535-115-00 TERMINAL TB703 *1-508-831-12 H TYPE BASE POST TM700 1-536-706-00 TERMINAL BOARD (SP) (SPEAKER)	RV306	1-241-022-11	RES, VAR, CARBON 150K/150K (BALANCE)
RV402 1-241-021-11 RES, VAR, SLIDE 250K (330Hz) RV403 1-241-021-11 RES, VAR, SLIDE 250K (1KHz) RV404 1-241-021-11 RES, VAR, SLIDE 250K (3.3KHz) RV405 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV501 1-228-990-00 RES, ADJ, CARBON 1K RV601 1-228-990-00 RES, ADJ, CARBON 1K RY901 1-515-701-11 RELAY S1 1-554-303-21 SWITCH, KEY BOARD (PHONO) S2 1-554-303-21 SWITCH, KEY BOARD (TUNER) S3 1-554-303-21 SWITCH, KEY BOARD (TAPE) S5 1-554-303-21 SWITCH, KEY BOARD (VIDEO) S6 1-554-303-21 SWITCH, KEY BOARD (DBFB) S7 1-554-303-21 SWITCH, KEY BOARD (DBFB) S7 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) S500 1-571-861-11 TRANSFORMER, POWER T1 ⚠ 1-450-068-11 TRANSFORMER, POWER T2 ⚠ 1-449-993-21 TRANSFORMER, POWER TB502 *1-535-115-00 TERMINAL TB602 *1-535-115-00 TERMINAL TB703 *1-508-831-12 TERMINAL TERMINAL THYPE BASE POST TM700 1-536-706-00 TERMINAL BOARD (SP) (SPEAKER)	RV307		RES, VAR, CARBON(MOTOR) 100KX2 (VOLUME)
RV403 1-241-021-11 RES, VAR, SLIDE 250K (1KHz) RV404 1-241-021-11 RES, VAR, SLIDE 250K (3.3KHz) RV405 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV501 1-228-990-00 RES, ADJ, CARBON 1K RV601 1-228-990-00 RES, ADJ, CARBON 1K RY901 1-515-701-11 RELAY S1 1-554-303-21 SWITCH, KEY BOARD (PHONO) S2 1-554-303-21 SWITCH, KEY BOARD (TUNER) S3 1-554-303-21 SWITCH, KEY BOARD (TUNER) S5 1-554-303-21 SWITCH, KEY BOARD (TAPE) S5 1-554-303-21 SWITCH, KEY BOARD (VIDEO) S6 1-554-303-21 SWITCH, KEY BOARD (DBFB) S7 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) S500 1-571-861-11 SWITCH, ROTARY SLIDE T1 1-450-068-11 TRANSFORMER, POWER T1 1-450-068-11 TRANSFORMER, POWER T1 1-535-115-00 TERMINAL TB602 *1-535-115-00 TERMINAL			
RV404 1-241-021-11 RES, VAR, SLIDE 250K (3.3KHz) RV405 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV501 1-228-990-00 RES, ADJ, CARBON 1K RV601 1-228-990-00 RES, ADJ, CARBON 1K RY901 1-515-701-11 RELAY S1 1-554-303-21 SWITCH, KEY BOARD (PHONO) S2 1-554-303-21 SWITCH, KEY BOARD (TUNER) S3 1-554-303-21 SWITCH, KEY BOARD (CD) S4 1-554-303-21 SWITCH, KEY BOARD (TAPE) S5 1-554-303-21 SWITCH, KEY BOARD (VIDEO) S6 1-554-303-21 SWITCH, KEY BOARD (VIDEO) S6 1-554-303-21 SWITCH, KEY BOARD (DBFB) S7 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) S7 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) S7 1-554-303-21 SWITCH, ROTARY SLIDE T1 ★1-450-068-11 TRANSFORMER, POWER T2 ★1-449-993-21 TRANSFORMER, POWER TB502 *1-535-115-00 TERMINAL TB602 *1-535-115-00 TERMINAL TB703 *1-508-831-12 H TYPE BASE POST TM700 1-536-706-00 TERMINAL BOARD (SP) (SPEAKER)			
RV405 1-241-021-11 RES, VAR, SLIDE 250K (10KHz) RV501 1-228-990-00 RES, ADJ, CARBON 1K RV601 1-228-990-00 RES, ADJ, CARBON 1K RY901 1-515-701-11 RELAY S1 1-554-303-21 SWITCH, KEY BOARD (PHONO) S2 1-554-303-21 SWITCH, KEY BOARD (TUNER) S3 1-554-303-21 SWITCH, KEY BOARD (CD) S4 1-554-303-21 SWITCH, KEY BOARD (TAPE) S5 1-554-303-21 SWITCH, KEY BOARD (VIDEO) S6 1-554-303-21 SWITCH, KEY BOARD (DBFB) S7 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) S500 1-571-861-11 SWITCH, ROTARY SLIDE T1 ★1-450-068-11 TRANSFORMER, POWER T2 ★1-449-993-21 TRANSFORMER, POWER TB502 *1-535-115-00 TERMINAL TB602 *1-535-115-00 TERMINAL TB703 *1-508-831-12 H TYPE BASE POST TM700 1-536-706-00 TERMINAL BOARD (SP) (SPEAKER)	11.1.403	1 241 021 11	, ,
RV501 1-228-990-00 RES, ADJ, CARBON 1K RV601 1-228-990-00 RES, ADJ, CARBON 1K RY901 1-515-701-11 RELAY S1 1-554-303-21 SWITCH, KEY BOARD (PHONO) S2 1-554-303-21 SWITCH, KEY BOARD (TUNER) S3 1-554-303-21 SWITCH, KEY BOARD (CD) S4 1-554-303-21 SWITCH, KEY BOARD (TAPE) S5 1-554-303-21 SWITCH, KEY BOARD (VIDEO) S6 1-554-303-21 SWITCH, KEY BOARD (DBFB) S7 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) S500 1-571-861-11 SWITCH, ROTARY SLIDE T1			
RY601 1-228-990-00 RES, ADJ, CARBON 1K RY901 1-515-701-11 RELAY S1 1-554-303-21 SWITCH, KEY BOARD (PHONO) S2 1-554-303-21 SWITCH, KEY BOARD (TUNER) S3 1-554-303-21 SWITCH, KEY BOARD (CD) S4 1-554-303-21 SWITCH, KEY BOARD (TAPE) S5 1-554-303-21 SWITCH, KEY BOARD (VIDEO) S6 1-554-303-21 SWITCH, KEY BOARD (DBFB) S7 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) S500 1-571-861-11 SWITCH, ROTARY SLIDE T1			
S1 1-554-303-21 SWITCH, KEY BOARD (PHONO) S2 1-554-303-21 SWITCH, KEY BOARD (TUNER) S3 1-554-303-21 SWITCH, KEY BOARD (CD) S4 1-554-303-21 SWITCH, KEY BOARD (TAPE) S5 1-554-303-21 SWITCH, KEY BOARD (VIDEO) S6 1-554-303-21 SWITCH, KEY BOARD (DBFB) S7 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) S500 1-571-861-11 SWITCH, ROTARY SLIDE T1			
S1 1-554-303-21 SWITCH, KEY BOARD (PHONO) S2 1-554-303-21 SWITCH, KEY BOARD (TUNER) S3 1-554-303-21 SWITCH, KEY BOARD (CD) S4 1-554-303-21 SWITCH, KEY BOARD (TAPE) S5 1-554-303-21 SWITCH, KEY BOARD (VIDEO) S6 1-554-303-21 SWITCH, KEY BOARD (DBFB) S7 1-554-303-21 SWITCH, KEY BOARD (SYSTEM POWER) S500 1-571-861-11 SWITCH, ROTARY SLIDE T1	RY901	1-515-701-11	RFLAY
\$\frac{1}{52} \qua	1(1501	1 313 701 11	
\$\begin{array}{cccccccccccccccccccccccccccccccccccc			
\$\frac{1}{54} \qquad \qquad \qquad \qquad \qquad \qquad \qqqq \qqqqq \qqqq \qqqq \qqqq \qqqq \qqqq \qqqq \qqqqq \qqqqq \qqqqq \qqqqq \qqqqq \qqqqqq			
\$6			
\$\frac{1}{57}\$ \text{1-554-303-21} \text{SWITCH, KEY BOARD (\$YSTEM POWER)} \text{SWITCH, ROTARY SLIDE}\$ \$\frac{1}{1}\$ \text{1-450-068-11} \text{TRANSFORMER, POWER} \\ \$\frac{1}{2}\$ \text{1-449-993-21} \text{TRANSFORMER, POWER} \\ \$\frac{1}{2}\$ \text{1-535-115-00} \text{TERMINAL} \\ \$\frac{1}{2}\$ \text{1-535-115-00} \text{TERMINAL} \\ \$\frac{1}{2}\$ \text{1-508-831-12} \text{1-770-8ASE POST} \\ \$\frac{1}{2}\$ \text{1-536-706-00} \text{TERMINAL BOARD (\$P) (\$PEAKER)} align*	S5	1-554-303-21	SWITCH, KEY BOARD (VIDEO)
\$\frac{1}{550}\$ \frac{1-554-303-21}{1-571-861-11}\$ \text{SWITCH, KEY BOARD (SYSTEM POWER)}\$ \text{SWITCH, ROTARY SLIDE}\$ \\ \text{T1} \text{\Lambda} \frac{1-450-068-11}{1-449-993-21}\$ \text{TRANSFORMER, POWER}\$ \\ \text{TB502} \text{1-535-115-00} \text{TERMINAL}\$ \\ \text{TB602} \text{1-535-115-00} \text{TERMINAL}\$ \\ \text{TB703} \text{1-508-831-12} \text{TYPE BASE POST}\$ \\ \text{TM700} \text{1-536-706-00} \text{TERMINAL BOARD (SP) (SPEAKER)}\$	S6	1-554-303-21	SWITCH, KEY BOARD (DBFB)
T1	S7		
T2	S500	1-571-861-11	SWITCH, ROTARY SLIDE
TB502 *1-535-115-00 TERMINAL TB602 *1-535-115-00 TERMINAL TB703 *1-508-831-12 H TYPE BASE POST TM700 1-536-706-00 TERMINAL BOARD (SP) (SPEAKER)	T1 /	<u>^</u> .1-450-068-11	TRANSFORMER, POWER
TB602 *1-535-115-00 TERMINAL TB703 *1-508-831-12 H TYPE BASE POST TM700 1-536-706-00 TERMINAL BOARD (SP) (SPEAKER)	T2 /	<u>^</u> .1-449-993-21	TRANSFORMER, POWER
TB602 *1-535-115-00 TERMINAL TB703 *1-508-831-12 H TYPE BASE POST TM700 1-536-706-00 TERMINAL BOARD (SP) (SPEAKER)	TB502	*1-535-115-00	TERMINAL
TM700 1-536-706-00 TERMINAL BOARD (SP) (SPEAKER)	TB602	*1-535-115-00	
	TB703	*1-508-831-12	H TYPE BASE POST
X901 1-577-077-11 OSCILLATOR, CERAMIC (400Hz)	TM700	1-536-706-00	TERMINAL BOARD (SP) (SPEAKER)
	X901	1-577-077-11	OSCILLATOR, CERAMIC (400Hz)

Ref.No	Part No.	Description
		S & PACKING MATERIALS *************
	* 4-927-885-01	MANUAL, INSTRUCTION

Note: The components identified by mark A or dotted line with mark A are critical for safety.

Replace only with part number specified.

-30-